

DeskMakers




ML Height Adjustable Mechanism User Guide

Please Read This Instruction Guide Before Operation

Table of Contents	2
Digital Handset Operation	3
Two-Key Handset Operation	7
Trouble Shooting	8
Connect Instructions	9-10

Digital Handset Operation

1. Panel



2. Initialization Procedure

Step	Operation	Motion
1	Press and Hold V & ^ Simultaneously for more than 3 seconds	Legs move down at half speed of normal operation
2	Keep pressing V & ^	Legs move down to the lowest position and rebound 2-5 mm, then stop
3	Release V & ^ together	Initialization is completed

Note: The Initialization Procedure must be completed before the first running after table is installed or parts replaced

3. Move Up and Down

Step	Operation	Motion
1	Press and Hold ^	Legs move up
2	Release ^	Legs stop
3	Press and Hold V	Legs move down
4	Release V	Legs Stop

4. Set Memory Positions

Step	Operation	Motion
1	Press and Hold \wedge or \vee	Run the legs to the position you want the table surface to be.
2	Click button S, then click button 1, 2 or 3 within next 3 seconds	Position 1,2 or 3 is saved

5. Move to the Memorized Position

Step	Operation	Motion
1	Press and Hold the Button 1, 2, or 3	Legs return to the corresponding position saved

6. Toggle the Display Unit Format

Step	Operation	Motion
1	Press and hold button S, then press and hold \vee , keep for about 3 seconds	The height information will be changed between centimeters and inches
2	Release the buttons	Completed

Note: In inch format, the minimum height variation as the legs move up or down is 0.5 inches, while in centimeter format is 1 centimeter.

7. Verify the Display Switch Data to Table Height

Step	Operation	Motion
1	Set the table at any height, recommended at the bottom position	Measure the table actual height and write down the number in inches or in centimeters
2	Press and hold button S, then press and hold \wedge , keep for about 3 seconds	The first number starts flashing on the screen
3	Release the buttons, then click \wedge or \vee to change the first number	The first number is being increased or decreased to the first number you measured
4	Click button S	The second number starts flashing on the screen
5	Click \wedge or \vee to change the number	The second number is being increased or decreased to the second number you measured
6	Click button S	The third number starts flashing on the screen
7	Click \wedge or \vee to change the number	The third number is being increased or decreased to the third number you measured
8	Click button S	Completed

Note: Check the switch display format in inches or in centimeters and toggle to the unit you like and match to the actual measurement. In inch format, the minimum adjustable height is 0.5 inches, while in centimeter format is 1 centimeter.

8. Lock the Stroke

Step	Operation	Motion
1	Press and hold \wedge or \vee , then release	Run the legs to the position you want the table surface to be
2	Press and hold button S, then press and hold 1, keep for about 3 seconds	Letter "L" is indicated on the screen. That means the position is locked at the lowest position that the table can be moved to
3	Release the buttons	Completed


***Note: 1. Legs aren't able to run below the locked position
2. Memory position(s) are/is below the locked position will be lost even after the table is unlocked, you need to follow SET MEMORY POSITIONS again to reset these memory positions.***

9. Unlock the Stroke

Step	Operation	Motion
1	Press and hold button S, then press and hold 2, keep about 3 seconds	Letter "C" is indicated on the screen. That means the table's unlocked and can be moved in full range
2	Release the buttons	Completed

Two-Key Handset Operation

1. Panel



2. Initialization Procedure

Step	Operation	Motion
1	Press and hold ▲&▼ simultaneously for more than 3 seconds	Legs begin to move down at half speed of normal operation
2	Keep pressing ▲&▼	Legs move down to the lowest position and rebound 2-5 mm, then stop
3	Release ▲&▼ together	Initialization is completed

Note: The Initialization Procedure must be completed before the first running after table is installed or parts replaced

3. Move Up and Down

Step	Operation	Motion
1	Press and hold ▲	Legs move up
2	Release ▲	Legs stop
3	Press and hold ▼	Legs move down
4	Release ▼	Legs stop

Trouble Shooting

Fault Phenomenon	Handling
After connecting the power, press up or down, the legs have no response.	Re-initialize the table; Check if the connection is correct or not; Please contact your supplier.
After connecting the power, press and hold up & down together, the legs have no response.	Check if the connection is correct or not; Please contact your supplier.
The legs rising slowly.	Check if the input power is correct or not; Please contact your supplier.
The legs don't move according to your operation.	Please contact your supplier.
One leg moves while the other leg does not move.	Check if the connection is correct or not; Please contact your supplier.
Legs only move down and don't move up.	Re-initialize the table; Please contact your supplier.
Table slides down itself.	Check if the weight of the load on the table exceeds 75KG or not; Please contact your supplier.
The table goes into initialization frequently.	Check if the weight of the load on the table exceeds 75KG or not; Check the noise of the motor; Please contact your supplier.

Connect Instructions



Step	Operation	Motion
1/2	Digital/Two-key Handset	Select one of the handsets and connect
3&4	Legs of desk	Connect the legs with the control box
5	Two-leg Control Box	Please check the power outlet voltage according to the label on the control box
6/7	Connecting Wire/Power Wire	Connect according to the arrow direction

Connect Instructions



Step	Operation	Motion
1/2	Digital/Two-key Handset	Select one of the handsets and connect
3&4&5	Legs of desk	Connect the legs with the control box
6	Three-leg Control Box	Please check the power outlet voltage according to the label on the control box
7/8/9	1m Connecting Wire/1.5m Connecting Wire/Power Wire	Connect according to the arrow direction